

# How to disassemble High Performance Disassembly instruction type 441



# Objectives of this Presentation. Increase special knowledge.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

Aim of this presentation is to give an overview about the **disassembly of High Performance safety valve type 441**.



**LESER**

[The-Safety-Valve.com](http://The-Safety-Valve.com)

# General. High Performance Safety Valves.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

---

LESER **High Performance** safety valves are the ultimate solution for all industrial applications for steam, gas and liquid. They were used e.g. for protection of chemical processes and equipment and for heat exchangers.

## Advantages:

- Great variety
- Soft seal for increased tightness
- Valve sizes from DN 20 to DN 400
- Great variety of materials and options to fit any application
- High capacity compared to the API requirements




**LESER**

[The-Safety-Valve.com](http://The-Safety-Valve.com)

# General Illustration.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## Cross-section view of High Performance 441



**LESER**

The-Safety-Valve.com

# Disassembly of the type 441. 1. Disassembly of the O-ring damper. 1.1

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 1.1 O-ring damper H4 (Option code: J66).

### Step 1.1-1

- Unscrew the lever with an open-end spanner
- Tools: Open-end spanner



### Step 1.1-2

- Remove the cap - spring - support sleeve - first O-ring - counter ring - second O-ring from the lever one after the other



**LESER**

The-Safety-Valve.com

# Disassembly of the type 441. 1. Disassembly of the O-ring damper. 1.1

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 1.1 O-ring damper H4 (Option code: J66).

### Step 1.1-3

- Individual parts of the O-ring damper



### Step 1.1-4

- Remove the retaining clip and steel pin from the spindle
- Pull the O-ring damper spindle off the valve spindle



# Disassembly of the type 441. 1. Disassembly of the O-ring damper

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 1.2 O-ring damper H2 (Option code: J65).

### Step 1.2-1

- Loosen cap
- Tools: Open-end spanner



### Step 1.2-2

- Remove cap
- Remove pressure spring from opposite ring



### Step 1.2-3

- Take counter ring from the O-ring or support sleeve



# Disassembly of the type 441. 1. Disassembly of the O-ring damper. 1.2

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 1.2 O-ring damper H2 (Option code: J65).

### Step 1.2-4

- Pull O-ring off the spindle



### Step 1.2-5

- Remove the support sleeve from the adjusting screw



### Step 1.2-6

- Individual parts of the O-ring damper H2





# Disassembly of the type 441. 2. Disassembly of the test gag / blocking screw.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## Step 2-1

- Loosen the test gag in the cap or lever and remove
- Tools: Open-end spanner



## 3. Disassembly of the lift indicator

### Step 3-1

- Remove lock nut
- Release second nut
- Remove lift indicator completely



# Disassembly of the type 441. 4. Disassembly of the cap/lever 4.1.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 4.1 Disassembly of the cap H2.

### Step 4.1-1

- Loosen cap with a spanner and screw off
- Tools: Open-end spanner



### Step 4.1-2

- Caution: The sealing ring may only be used once
- If it is necessary to dismantle the cap, the sealing ring must be replaced



# Disassembly of the type 441. 4. Disassembly of the cap/lever 4.2.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 4.2 Disassembly of the lever H3.

### Step 4.2-1

- Remove the clamping screw on the lever
- Tools: Open-end spanner, ring spanner



### Step 4.2-2

- Push the retaining washers off the pin
- Tools: Pliers



### Step 4.2-3

- Pull pin out
- Pull lever out of the cap



# Disassembly of the type 441. 4. Disassembly of the cap/lever

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 4.2 Disassembly of the lever H3.

### Step 4.2-4

- Remove small plastic ball and unscrew screw
- Tools: Ring spanner



### Step 4.2-5

- Remove the retaining clip and pin from the spindle cap
- Pull the spindle cap off the spindle



# Disassembly of the type 441. 4. Disassembly of the cap/lever 4.3.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 4.3 Disassembly of the lever H4.

### Step 4.3-1

- Loosen lever and screw it off
- Tools: Open-end spanner



### Step 4.3-2

- Remove retaining clip and pin
- Pull spindle cap off the spindle



# Disassembly Type 441. 5. Disassembly: pressure spring & adjusting screw.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## Step 5-1

- Remove lock nut from adjusting screw
- Tools: Open-end spanner



## Step 5-2

- Secure the spindle from turning with a pin punch
- Apply the open-end spanner in a clockwise direction until the springs are unstressed
- Tools: Open-end spanner, pin punch



# Disassembly Type 441. 5. Disassembly: pressure spring & adjusting screw.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## Step 5-3

- Screw adjusting screw out of the bonnet



## Step 5-4

- Unscrew the lock nut



## Step 5-5

- Remove the plastic bush




# Disassembly of the type 441. 6. Disassembly of the bonnet

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 6.1 Disassembly of the bonnet DN 80.

### Step 6.1-1

- Loosen the nuts and unscrew them from the studs
- Tools: Open-end spanner Ratchet



### Step 6.1-2

- Carefully lift off and remove the bonnet from the body by hand or crane depending on the size and weight





# Disassembly Type 441. 6. Disassembly of the bonnet. 6.2

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 6.2 Disassembly of the bonnet DN 65.


### Step 6.2-1

- Loosen the nuts and unscrew them from the studs
- Tools: Open-end spanner Ratchet



### Step 6.2-2

- Carefully lift off and remove the bonnet from the body



# Disassembly Type 441. 7. Removing the assembly. 7.1

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.1 Disassembly of the spring/disc/bellows/cooling zone assembly.

### Step 7.1-1

- If there are any thrust bearings, remove them from the top spring plate
- Pull the spring plate off the spindle



### Step 7.1-2

- Pull spring(s) off the spindle




# Disassembly Type 441. 7. Removing the assembly. 7.1

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.1 Disassembly of the spring/disc/bellows/cooling zone assembly.

### Step 7.1-3

- Lift out the spindle with the bottom spring plate, guide, bellows if applicable and disc from the body



### Step 7.1-4

- Remove the cooling zone / bonnet extender from the body
- Remove gaskets



# Disassembly Type 441. 7. Removing the assembly. 7.2

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.2 Disassembly of the spindle/disc assembly (with elastomer bellows).

### Step 7.2-1

- Lift of the top spring plate and spring off the spindle one after the other



### Step 7.2-3

- Remove the hose clamp from the spring plate with pliers
- Tools: Pliers



### Step 7.2-2

- Remove the retaining clip
- Remove the split rings from the spindle



# Disassembly Type 441. 7. Removing the assembly. 7.2

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.2 Disassembly of the spindle/disc assembly (with elastomer bellows).

### Step 7.2-4

- Pull the guide with the elastomer bellows off the spindle



### Step 7.2-5

- Remove the hose clamp with pliers
- Tools: Pliers



### Step 7.2-6

- Pull the elastomer bellows off the guide



# Disassembly Type 441. 7. Removing the assembly. 7.2

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.2 Disassembly of the spindle/disc assembly (with elastomer bellows).

### Step 7.2-7

- Dismantle the spindle-disc connection




### Step 7.2-9

- Separate the spindle and disc



### Step 7.2-8

- Push the pin out of the spindle



# Disassembly Type 441. 7. Removing the assembly. 7.3

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.3 Disassembly of the spindle/disc assembly (with stainless steel bellows).

### Step 7.3-1

- Remove the bottom spring plate



### Step 7.3-3

- Pull off the guide



### Step 7.3-2

- Remove the retaining clips from the spindle
- Remove retaining clip from split rings



# Disassembly Type 441. 7. Removing the assembly. 7.3

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.3 Disassembly of the spindle/disc assembly (with stainless steel bellows).

### Step 7.3-4

- Remove sealing ring from bellows



### Step 7.3-6

- Drive out the pin
- Separate the stainless steel bellows and disc



### Step 7.3-5

- Remove lift stopper, if this is present





# Disassembly Type 441. 7. Removing the assembly. 7.4

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.4 Disassembly of the spindle/disc assembly (without bellows).


### Step 7.4-1

- Remove the top spring plate, spring and bottom spring plate from the spindle one after the other



### Step 7.4-2

- Remove retaining clip
- Remove split rings



### Step 7.4-3

- Push the guide off the spindle



# Assembly of the Type 441. 7. Removing the assembly. 7.4

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441

## 7.4 Disassembly of the spindle/disc assembly (without bellows).

### Step 7.4-4

- Remove the lift stopper if this is present




### Step 7.4-6

- Take the ball out of the disc body



### Step 7.4-5

- Drive out the pin
- Separate the plate and disc



# Disassembly of the Type 441. 8. Unscrew the studs from the body.

[1. Objectives](#) | [2. General](#) | [3. General Illustration](#) | [4. Disassembly instruction Type 441](#)

## Step 8-1

- Remove studs with impact wrench
- Tip: Place the guide on the opening of the body so that no studs can fall on the seat
- Tools: Impact wrench




# Disassembly of the Type 441. 9. Disassembly of the nozzle.

1. Objectives | 2. General | 3. General Illustration | 4. Disassembly instruction Type 441


## Step 9-1

- Remove nozzle with C-spanner (put a small protective plate between the nozzle and C-spanner)
- Tools: C-spanner with nose



## Step 9-2

- Unscrew nozzle from the body



**How to disassemble High Performance**  
Thank you for your attention.



**LESER**

The-Safety-Valve.com